### **Electrical Control for Machines 7th Edition Lobsiger Test Bank**

Full Download: http://testbanklive.com/download/electrical-control-for-machines-7th-edition-lobsiger-test-bank/

Chapter 2 - Fuses, Disconnect Switches, and Circuit Breakers

### **TRUE/FALSE**

1. The 120 VAC circuit is normally protected by a single fuse or circuit breaker.

ANS: T	PTS: 1	<b>REF:</b> Protective Factors
--------	--------	--------------------------------

2. Switching voltage surges are usually limited to three times normal voltage.

ANS: T PTS: 1 **REF:** Voltage and Frequency Surges

3. By programming a motor-protective relay unit with the motor's electrical characteristics, the unit's algorithm will automatically tailor the optimal protection curve to the motor being monitored.

ANS: T	PTS: 1	<b>REF:</b> Programmable Motor Protection
--------	--------	---

## **MULTIPLE CHOICE**

- 1. The typical fuse consists of an element surrounded by a filler and enclosed by the fuse body. The element is a calibrated \_\_\_\_\_. a. insulator c. conductor
  - b. transistor d. capacitor
  - ANS: C PTS: 1 **REF:** Fuse Construction and Operation
- 2. Peak let-thru current  $(I_p)$  and ampere squared seconds  $(I_{2t})$  are two measures for the degree of \_\_\_\_\_ provided by a fuse.
  - a. current limitation c. circuit isolation b. time delay d. rectification

ANS: A PTS: 1 REF: Peak Let-Thru Current (Ip) and Ampere Squared Seconds (I2t)

is the current-limiting characteristic of a transformer and is expressed as a percent. 3. Canacitance c Ampacity

b. Impedance				Rectification
ANS: B	PTS:	1	REF:	Selecting Protective Devices

4. The main purpose of a ground fault circuit interrupter (GFCI) is to \_\_\_\_\_. a. determine the interrupting capacity

- c. protect a person from electrical shock
- d. gauge the ambient temperature

ANS: C PTS: 1 **REF:** Ground Fault Circuit Interrupter

## **COMPLETION**

1. All protective devices have a published , which is defined as the highest current at rated voltage that a device can safely interrupt.

ANS: interrupting capacity

b. calculate the available current

# **Electrical Control for Machines 7th Edition Lobsiger Test Bank**

Full Download: http://testbanklive.com/download/electrical-control-for-machines-7th-edition-lobsiger-test-bank/

PTS: 1 REF: Fuse Types

2. \_\_\_\_\_\_ fuses are used today in almost all fuse applications.

ANS: Current-limiting time-delay Current limiting time delay

PTS: 1 REF: Fuse Types

3. Adding a(n) \_\_\_\_\_\_ to the nonautomatic circuit breaker, by using a bimetallic element in each pole of the breaker, provides automatic tripping.

ANS: thermal trip unit

PTS: 1 REF: Circuit Breaker Types